RAZER KISHI V2 FOR iPHONE

MASTER GUIDE

Rethink everything you knew about mobile gaming. **Razer Kishi V2** is a universal mobile gaming controller that brings a console-class gameplay experience to your iPhone. Play the best AAA games, on your iPhone, exactly as you'd expect to play them on a game console – zero compromises.

CONTENTS

1. WHAT'S INSIDE 3

2. WHAT'S NEEDED 4

3. LET'S GET YOU COVERED 4

4. GETTING STARTED 5

5. USING THE CONTROLLER 6

6. SAFETY AND MAINTENANCE 8

7. LEGALESE 9

1. WHAT'S INSIDE

- Razer Kishi V2 for iPhone



A. Clickable analog thumbsticks (L3/R3)
B. Options button
C. D-pad
D. Share button
E. Extendable bridge
F. Lightning connector
G. Face buttons
H. Razer Nexus button
I. Menu button
J. Lightning port*
K. Bumpers (L1/R1)
L. Multi-function buttons (L4 / R4)
M. Triggers (L2/R2)

**Only supports passthrough charging. Lightning headphones and other accessories are not supported*.

- Rubber cushions**
- Important Product Information Guide

***Pre-installed with the controller.*

2. WHAT'S NEEDED

- iOS 15.4 or higher**
- Internet connection for app installation

***Compatible with iPhone 11, iPhone 11 Pro, iPhone 11 Pro Max, iPhone 12, iPhone 12 Pro, iPhone 12 Pro Max, iPhone 13, iPhone 13 Pro, and iPhone 13 Pro Max.*

3. LET'S GET YOU COVERED



Register your product and score exclusive benefits

razerid.razer.com/warranty

4. GETTING STARTED

SETTING IT UP



INSTALL THE RAZER NEXUS APP

Launch compatible titles, remap controller buttons, take screenshots, record and share your gameplay, and much more – anytime and anywhere.

Razer Nexus

Download on the App Store

RZR.TO/NEXUS-IOS

5. USING THE CONTROLLER

DETACHING YOUR PHONE



USING THE LIGHTNING PORT FOR PASSTHROUGH CHARGING



Only supports passthrough charging.

REMOVING THE RUBBER CUSHIONS

The pre-installed rubber cushions can be removed if you want to see whether your case-fitted phone fits into the controller.



6. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer Kishi V2 for iPhone, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, make sure to unplug the device (if applicable) and contact the Razer hotline or go to support.razer.com for support.

Don’t take apart the device, and don’t attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, detach the device to let its temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Kishi V2 for iPhone requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you clean the device using a soft cloth or cotton swab to prevent dirt buildup.

7. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2022 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, and “For Gamers. By Gamers.”are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Apple, Apple TV, Apple Watch, iPad, iPad Air, iPad Pro, iPhone, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.

tvOS is a trademark of Apple Inc.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Kishi V2 for iPhone (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.